

GENERAL INFORMATION

Regarding hinge load values
Reference value **80 kg**

Overview of load values for hinges

For medium duty applications where hinges are installed on doors in housing, other living areas and in buildings where there is a medium frequency of use by people with some incentive to exercise care and with some chance of accidents occurring or of misuse. This description represents the typical “residential door” for which Anselmi hinges have been developed.

An example of a door leaf with dimensions of 900 x 2100 mm (W x H), the use of 2 hinges is recommended and a hinge gap of 1700 mm, the permissible load values change with different width and height ratios.

The following table provides an overview of the maximum load value for the individual hinge type, taking the interaction of width and height of the door as well as the hinge gap into account.

Blue load value = reference value. **Green** load value < reference value.

Door height mm	Hinge gap mm									
2800	2400	80	80	80	80	80	80	80	80	80
2700	2300	80	80	80	80	80	80	80	80	80
2600	2200	80	80	80	80	80	80	80	80	80
2500	2100	80	80	80	80	80	80	80	80	80
2400	2000	80	80	80	80	80	80	80	74	74
2300	1900	80	80	80	80	80	80	78	70	70
2200	1800	80	80	80	80	80	80	74	66	66
2100	1700	80	80	80	80	80	76	68	64	64
2000	1400	80	80	80	78	72	64	60	60	60
		600	750	800	900	1000	1100	1200		

l → Leaf width in mm

The use of a third hinge positioned in the middle of the door leaf has no influence on the load capacity of the hinge system. However, in case of particularly high doors (above 2200 mm), doors positioned in rooms with high levels of humidity (i.e. bathrooms) or doors between rooms with different temperatures (i.e. stairwell) and doors produced with light material (i.e. honeycomb) the use of more than two hinges is suggested in order to prevent the door from warping.

The specifications above are guidelines. Especially in the case of borderline load requirements, please approach us.

LOAD VALUES FOR HINGES

An accurate, professional fitting in accordance with the Anselmi installation instructions is always a prerequisite.

Installation site (residential building, public building, school, administration, barracks, kindergarten etc.)

Type of material of the element

Frequency of operation

Door dimensions (e.g. excess widths)

Positioning of hinges

Assembly of hinges

Outward opening doors (porch)

Door stop

Door closer

Swing-door operator

Wall soffits

Closing sequence control systems, etc.

When selecting or deciding on a hinge, the loading (stress factor) is often viewed as being identical to the weight of the door. However, the actual hinge loading can often be several times the door weight, caused by various influential factors.

Even taking these variations of criteria into account, an additional margin of reserve should always be included when selecting the hinge.



In buildings where extra loads are incurred due to the high opening frequency and stress which is not always calculable i.e kindergarten, hospitals etc, sufficiently dimensioned hinges should be used even if this would not have been necessary merely based on the door weight. Our technicians are at your disposal to help identify the appropriate hinge system for your application.

Reference details

The load specifications for Anselmi hinges are based on a maximum door weight. Additionally, the listed influential factors must also be taken into account for actual hinge loads.

All indications are based on the following references:

Door leaf dimensions	900 x 2100 mm
Use of	2 hinges
Hinge distance	1700 mm



Third hinge position on extra wide doors

In addition to the factors mentioned above the use of a third hinge can have a significant impact on the load capacity. In practice often a third hinge is located in the middle of the door in order to meet the optical demands and to minimize warping in the centre of the door.

Under certain circumstances however it may be useful or even necessary to additionally support the upper hinge which takes most of the major tractive forces - this could be true, for instance, in the case of extra-wide doors (≥ 900 mm), where additional forces occur due to the lever action. For these applications the third hinge has to be located in the upper third of the door for the load capacity of the hinge to be positively influenced. In case of door widths equal or above 900 mm Anselmi suggests the use of a third hinge at 250 mm from the top hinge (centre to centre).

Door closers

Several models of Anselmi hinges have been tested in combination with door closers. When door closers are used, Anselmi recommends the use of a third hinge in the upper third of the door. The correct adjustment of the closer is a fundamental requirement for a long-lasting, problem-free function. It is recommended to get in touch with Anselmi to obtain the correct technical specifications.

Wall openings, door stoppers

Factors such as door stops, projecting walls or similar cannot be measured or estimated and need to be considered individually, due to the lever action and cantilever forces that may occur if the door is opened too far resp. beyond a defined level. As a result of the doors' masses/weights, this can quickly lead to damage to the fixings, the hinges or similar. If it is necessary to use a door stop, this should either be mounted on the wall or, instead, on the floor placed at 75% of the door's width away from the hinge axis in the direction of the lock.

Miscellaneous

The points given here are simply guidelines. In practice, it may make sense, depending on the door's composition, usage levels, location, etc., to take the above factors into account even for door widths ≤ 900 mm. This needs to be decided on a case-by-case basis. Care must be taken to ensure that the hinges are of a sufficient size to be able to cover the demanding factors.